



PRESSURE SWITCH RELIEF VALVE ADJUSTMENT

1. LOOSEN HEX NUT.
2. SELECT CORRECT SIZE OF ALLEN WRENCH.
3. TURN VALVE CLOCKWISE TO INCREASE PRESSURE, TURN COUNTER CLOCKWISE TO DECREASE PRESSURE.
4. TIGHTEN HEX NUT.



HYDRAULIC POWER UNIT
3 HP

DATE: 10-30-03
DRN BY PMW

2850

REV 2